

Hidden Springs Condominiums

715 Sandy Court, Altamonte Springs, FL 32714

(407) 862-3140 Office (407) 862-8727 Fax

REQUIREMENTS FOR INSTALLING CERAMIC TILE, WOOD FLOORING OR ANY OTHER FLOORING BESIDES CARPET

- 1. Plywood sub flooring must have a layer of gypsum on top. All floors should already have this.**
- 2. Glue down, with mastic under 1/2" hardi backer boards, screw down every 8" on center.**
- 3. Install soundproofing, the IMPACT INSULATION CLASS must have a minimum of 65 IIC and you must provide a sample and literature on the product**
- 4. If installing wood flooring, the flooring must be a minimum 12 – 13 mm and you must provide a sample and literature on the product**
- 5. High quality thin set (if installing tile)**
- 6. Take pictures of each step and turn into office when complete.**